

PlatformIO

Init mit QtCreator

- Init: `pio init -ide qtcreator -board nanoatmega328`
- Build: `pio run`
- Clean: `pio run -target clean`
- Deploy: `pio run -target upload`
- Run: `minicom -baudrate 115200 -device /dev/ttyACM0`
Don't forget to check Run in terminal

From:

<http://www.zeilhofer.co.at/wiki/> - **Verschiedenste Artikel von Karl Zeilhofer**

Permanent link:

<http://www.zeilhofer.co.at/wiki/doku.php?id=platformio>

Last update: **2019/01/26 11:22**

